



MOUNTING INSTRUCTIONS

1. INSTALL TWO MOUNTING SCREWS INTO THE WALL AT EYE LEVEL. USE THE PLASTIC WALL ANCHORS TO SECURE THE SCREW IF THE WALL IS DRYWALL OR MASONRY. LET THE SCREW HEAD EXTEND 1/4 INCH FROM THE WALL.
2. HANG THE CONTROLLER ON THE UPPER MOUNTING SCREWS.
3. INSTALL THE LOWER SCREWS TO SECURE THE ENCLOSURE TO THE WALL.