

**SET ONLY SUMMER WATERING MINUTES AND DAYS!**

**Normal Operation**

1. Set the Dial to *RUN* position.
- Note: The controller determines the watering duration based upon water use. On a cool day the controller may not water.

**Setting the Time/Date**

1. Set the Dial to *Time/Date* position.
2. Press *NEXT* to change month, day, year, hour and minute.
3. Press *MORE* or *LESS* to select the right value.

**Setting Days To Irrigate**

1. Set the Dial to *Days* position.
2. Press *MORE* to select program.
3. Press *NEXT* until an option item in the second line is flashing.
4. Press *MORE* to select option: *ODD DAYS, EVEN DAYS, SELECTED DAYS, SKIP DAYS* and *OFF*
5. With *S.M.T.W.T.F.S.* or *Skip Days* press *NEXT* to identify the day and *MORE* or *LESS* to select or cancel watering for that day.

**Setting Irrigation Start Times**

1. Set the Dial to *Times*.
2. Press *MORE* to select the program.
3. Press *NEXT* to select one of the four start times.
4. Press *MORE* or *LESS* to increase or decrease the hour or minute start times.
5. Press *NEXT* to select either the hour

**Setting Station Run-Times**

**SET CONTROLLER FOR SUMMER RUN-TIMES ONLY!**

1. Set the Dial to *Run-Time*.
2. Press *MORE* to select the station.
3. Press *NEXT* to select the program to water.
4. Press *MORE* or *LESS* to increase the minutes.
5. Press *NEXT* to select another program to water.

**Region/Accumulate Settings**

1. Set the Dial to *Settings*.
2. Press *MORE* or *LESS* to increase or decrease the region number.
3. Press *NEXT* to change / set program lock.
4. Press *NEXT* to change / set accumulation.
5. Press *MORE* or *LESS* to turn on or off accumulation feature.
6. See manual for more settings.

**Manual Mode**

1. Set the Dial to *Manual*.
2. Press *MORE* to select the station.
3. Press *NEXT* to change the run-time minutes.
4. Press *MORE* or *LESS* to increase or decrease the minutes of watering.
5. Set the Dial to run to begin watering.

**Rain Delay in RUN position**

1. With the Dial in the *RUN* position
2. Press *LESS/RAIN* to suspend watering for 24 hours.
3. Press *MORE* to select 1 to 5 days to suspend watering.



**Add a Day of Water/Test System**

1. With the Dial in the *RUN* position.
2. Press *MORE/TEST* to select "*Auto run all*", "*2 min test*", or Program *A, B, C* or *D*.
3. Press *NEXT* to activate the selection.

**Station Run Duration Displayed**

1. With the Dial in the *RUN* Position.
2. Holding *NEXT* will display today's run-time for each station.
3. Holding *PREVIOUS* will display the last seven days' total run-time for each station.

**Off**

1. Set the Dial to *OFF* to stop all watering.

**No. Color Prog Watering Zone**

1	_____	_____	_____
2	_____	_____	_____
3	_____	_____	_____
4	_____	_____	_____
5	_____	_____	_____
6	_____	_____	_____
7	_____	_____	_____
8	_____	_____	_____
9	_____	_____	_____
10	_____	_____	_____
11	_____	_____	_____
12	_____	_____	_____
13	_____	_____	_____
14	_____	_____	_____

Try to Conserve Water by  
Reducing Run-time Minutes

P/N LAB-0008 Rev. G 11-22-04

**SET ONLY SUMMER WATERING MINUTES AND DAYS!**

**Normal Operation**

1. Set the Dial to *RUN* position.

Note: The controller determines the watering duration based upon water use. On a cool day the controller may not water.

**Setting the Time/Date**

1. Set the Dial to *Time/Date* position.
2. Press *NEXT* to change month, day, year, hour and minute.
3. Press *MORE* or *LESS* to select the right value.

**Setting Days To Irrigate**

1. Set the Dial to *Days* position.
2. Press *MORE* to select program.
3. Press *NEXT* until an option item in the second line is flashing.
4. Press *MORE* to select option: *ODD DAYS, EVEN DAYS, SELECTED DAYS, SKIP DAYS* and *OFF*
5. With *S.M.T.W.T.F.S.* or *Skip Days* press *NEXT* to identify the day and *MORE* or *LESS* to select or cancel watering for that day.

**Setting Irrigation Start Times**

1. Set the Dial to *Times*.
2. Press *MORE* to select the

**Setting Station Run-Times**

**SET CONTROLLER FOR SUMMER RUN-TIMES ONLY!**

1. Set the Dial to *Run-Time*.
2. Press *MORE* to select the station.
3. Press *NEXT* to select the program to water.
4. Press *MORE* or *LESS* to increase the minutes.
5. Press *NEXT* to select another program to water.

**Region/Accumulate Settings**

1. Set the Dial to *Settings*.
2. Press *MORE* or *LESS* to increase or decrease the region number.
3. Press *NEXT* to change / set program lock.
4. Press *NEXT* to change / set accumulation.
5. Press *MORE* or *LESS* to turn on or off accumulation feature.
6. See manual for more settings.

**Manual Mode**

1. Set the Dial to *Manual*.
2. Press *MORE* to select the station.
3. Press *NEXT* to change the run-time minutes.
4. Press *MORE* or *LESS* to increase or decrease the minutes of watering.
5. Set the Dial to run to begin watering.

**Rain Delay in RUN position**

1. With the Dial in the *RUN* position
2. Press *LESS/RAIN* to suspend watering for 24 hours.
3. Press *MORE* to select 1 to 5 days to suspend watering.